



restart veconfigure and it should now default ESS to the older version.
Probably better to just update it providing it will let you (it should).
[Reply](#) · [Share](#) · [More](#)

Write an Answer

