## Venus OS 3.20 MQTT setup

From the Version 3.20 on will no longer work without a user (anonymous).
we have to create a user with a password.
for doing this we use a password creator.
Software link for Password Generator
https://dmelo.eu/mosquitto_passwd_gen/
in the screenshot below we have created a user with the following credentials  User: CerboMQTT  Password: CerboMQTT_Password_demo
Username
CerboMQTT
Password
CerboMQTT_Password_demo
Iterations
101
Generate
CerboMQTT:\$7\$101\$/We/ +riH6GL6w+G0\$ibRspYzpcEk8lZOPanz1SeYZXahNOYRJFmiz64DLPDYs

s1vpLKL5eVZK1cKOUB3vZHnWYLlCo7bb1v0pjnj+nw==

We will create a text file with the name flashmq\_user\_passwd.txt and we copy the generated text in the file. We can use this file with WinSCP.



Now we use putty and we will logon into the cerbo as root.

we will use the following command

cd /etc/flashmq

ls

we can see a flashmq.conf file

now we use the nano command for editing the flashmq.conf

nano flashmq.conf

we will add a line

mosquitto\_password\_file /etc/flashmq/flashmq\_user\_passwd.txt

```
192.168.178.45 - PuTTY
                                                                         Modified
 GNU nano 4.9.3
                                      flashmq.conf
listen {
 protocol mqtt
 port 1883
listen {
 protocol mqtt
 port 8883
 fullchain /data/keys/mosquitto.crt
 privkey /data/keys/mosquitto.key
listen {
 protocol websockets
 port 9001
mosquitto password file /etc/flashmq/flashmq user passwd.txt
                                        ^K Cut Text
  Get Help
                Write Out
                          ^W Where Is
                                                         Justify
                Read File
```

we save the modified flashmq.conf file.


now we have to create flashmq\_user\_passwd.txt file or we can copy the file we created with the software WinSCP

(https://winscp.net/eng/index.php)

we use the nano command

nano /etc/flashmq/flashmq\_user\_passwd.txt

we will copy the generated key into and save it.



We can add much users as we need.

we will reboot the cerbo or the raspi\_venus with the command reboot.

Now we can use the MQTT function as before.